



ON TIME WILDLIFE FEEDERS IS NOT RESPONSIBLE FOR VARMINT DAMAGE TO YOUR FEEDER UNIT. HEAVY SCREEN WIRE IS RECOMMENDED TO SHIELD YOUR UNIT FROM VARMINTS.

RICE BRAN FEEDER INSTRUCTIONS ITEM# 73000

STEP 4: Setting the digital timer (CONTINUED).

STEP 7: Your display should look like FIGURE 6. At this point refer to STEP 4 and repeat as you did when setting your first feeding. The only difference will be the number 2 in the lower left hand side of the display which is indicating that this is concerning your second feed time. At this stage of programming your unit, if you do not want to use the second feed time, set the run time to 00. The display will automatically show "OFF". This will end the second feeding. Even though the second feed time was set, the run time being set to 00 will end your programming session. The screen will look like FIGURE 7.

FIGURE 7



STEP 8: If you choose to continue, set run time from 1 to 30 seconds, and while repeating STEPS 3 thru 5, take note to the small number in the lower left hand corner which will indicate which of the 6 possible feedings you are setting. After finishing this step press the SELECT/ENTER button, and the screen will appear like FIGURE 8.

FIGURE 8



STEP 9: Looking at figure 8 you see the word "Armed" which indicates that your unit is now in service. It will perform the commands that you have programmed. You can test your unit by pressing the test button. (This will set up a count down from 10-9-8----00 and at the 00 your unit will run for 5 seconds at a 100% motor speed.) Note that the 100% motor speed is regardless of any other speed you may have set. Once you confirm that the test has successfully run, your unit is ready for use.

NOTE: While working with your unit, if the buttons have not been pressed for two minutes, the screen will go blank.

This is a power saver feature. If the screen goes blank, you can press any key one time and restore the screen. However, if the screen is different from the one you were working with at the time it went blank, push the SELECT/ENTER button repeatedly until the screen you were working with appears. If you go past the screen – simply keep pressing the SELECT/ENTER button until your screen comes back around.

NOTE: The screen will indicate all characters for 1 second once the battery is installed. Then the screen will show 12:00PM. If no programming activity is initiated, the unit will automatically set itself at 12:00PM, Noon, for a 5 second run time.

TESTING THE UNIT: The test button can only be used while on the "ARMED" screen. Pressing the test button will sequence the screen to a countdown from 10 to 1. It will run when it reaches 0. The screen will return to "ARMED" automatically when the test is complete.

After setting the digital timer, reconnect the white power wire plug. The test feature on the digital timer should now function.

NOTE: Regardless of the number of seconds the unit is programmed to run, the test feature only runs for 5 seconds.

STEP 5: Fill the Unit. The On Time Rice Bran Feeder is designed to strictly run with rice bran only. Fill the unit with rice bran to 1 inch below the ring on the hopper where the lid is seated. You must leave room for the battery to extend into the hopper.

DO NOT pack the rice bran into the hopper. Simply pour rice bran directly in the hopper until the fill line is reached. This step is easiest with the unit flat on the ground, but use caution to not set on wet ground.

REFILLING: It is not necessary to unplug the white power wire plug when refilling. Using the supplied hook, place the large portion of the hook through one of the two vent holes on the side of the barrel lid. Hang the small end of the hook on the rim of the barrel. This will hold the lid out of the way while refilling the unit. The hook can also be stowed on the side of the hopper. See images on hardware page of instructions.

FINAL NOTE: Do not operate the unit without rice bran inside to avoid excessive wear and tear on the mechanisms.