

**INSTRUCTIONS FOR THE VL-25 TRIPOD**

**TOOL REQUIRED: 1/2" SOCKET WRENCH**  
THIS IS TO TIGHTEN THE 3 LEG BRACKET BOLTS




FIG. 1


STEP 1. INSTALL ONE OF THE THREE LEG BRACKETS AS ILLUSTRATED IN FIG. 1

*THIS STEP MAY BE EASIER IF THE HOPPER IS UP-SIDE DOWN*

INSTALL THE METAL WASHER ON THE 5/16" BOLT, THEN THE RUBBER WASHER. REACHING THRU THE 4" HOLE IN THE CONE, INSTALL THE BOLT ALONG WITH THE WASHERS FROM THE INSIDE OF THE BARREL. (NOTE: THE RUBBER WASHER WILL BE AGAINST THE INSIDE WALL OF THE HOPPER OR BARREL)


SEE FIG 3

INSTALL WASHERS IN THIS SEQUENCE: FIRST INSTALL METAL, THEN RUBBER.




STEP 2. INSTALL THE TWO REMAINING LEG BRACKETS AS ILLUSTRATED IN FIG. 1. USING THE BOLTS AND WASHERS FROM FIG. 3 THE FINISHED INSTALLATION SHOULD LOOK LIKE FIG. 2

STEP 3. INSTALL THE 3 LEGS ONTO THE LEG BRACKETS (EACH LEG IS MADE UP OF 3 SLIDE TOGETHER LEG SECTIONS. A TOTAL OF 9 LEG PIECES ARE IN A BOX CONTAINING THE LEG PIECES ONLY.



STEP 4. SLIDE LEGS TOGETHER AS SHOWN IN FIG. 4



STEP 6. INSTALL TIMER UNIT ONTO THE BOTTOM OF THE CONE SECTION. USE THE 4 SCREWS PACKED INSIDE TOMAHAWK TIMER BOX. A 5/16" NUT DRIVER, OR PHILLIPS HEAD SCREW DRIVER MAY BE USED.

STEP 5. FINISHED UNIT SHOULD LOOK LIKE THIS.

